


## Root-Locus, Rules 1–5



Defs. OLTF =  $G(s)H(s)$ ;  $n_p, n_z$  = number of poles, zeros of OLTF

Defs. Characteristic Polynomial (CP) =  $1 + KG(s)H(s)$

$$\Rightarrow \boxed{1 + KG(s)H(s) = 0 \Rightarrow K(s) = \frac{-1}{G(s)H(s)}}$$

**Rule 1** RL is always symmetric with respect to **the real-axis**—remember that

**Rule 2** RL has  $n$  branches,  $n = n_p$

**Rule 3** Mark poles ( $n_p$ ) and zeros ( $n_z$ ) of  $G(s)H(s)$  with 'x' and 'o'

**Rule 4** Each branch starts at OLTF poles ( $K = 0$ ), ends at OLTF zeros or at infinity ( $K = \infty$ )

**Rule 5** RL has branches on x-axis. These branches exist on real axis portions where the **total # of poles + zeros** to the right is an odd #

## Root-Locus, Rules 6–8

**Rule 6** Asymptotes angles: RL branches ending at OL zeros at  $\infty$  approach the asymptotic lines with angles:

$$\phi_q = \frac{(1 + 2q)180}{n_p - n_z} \text{ deg}, \forall q = 0, 1, 2, \dots, n_p - n_z - 1$$

**Rule 7** Real-axis intercept of asymptotes:

$$\sigma_A = \frac{\sum_{i=1}^{n_p} \text{Re}(p_i) - \sum_{j=1}^{n_z} \text{Re}(z_j)}{n_p - n_z}$$

**Rule 8-1** RL branches intersect the real-axis at points where  $K$  is at an extremum for real values of  $s$ . Remember that:

$$1 + KG(s)H(s) = 0 \Rightarrow K(s) = \frac{-1}{G(s)H(s)}$$

We find the breakaway points by finding solutions (i.e.,  $s^*$  solutions) to:

$$\frac{dK(s)}{ds} = 0 = -\frac{d}{ds} \left[ \frac{1}{G(s)H(s)} \right] = 0 \Rightarrow \frac{d}{ds} [G(s)H(s)] = 0 \Rightarrow \text{obtain } s^*$$

**Rule 8-2** After finding  $s^*$  solutions (you can have a few), check whether the corresponding  $K(s^*) = \frac{-1}{G(s^*)H(s^*)} = K^*$  is **real positive #**

**Rule 8-3** **Breakaway pt.:**  $K_{max}^*$  (-ve  $K''(s^*)$ ), **Break-in pt.:**  $K_{min}^*$  (+ve  $K''(s^*)$ )

## Root-Locus, Rules 9–10

**Rule 9 Angle of Departure (AoD):** defined as the angle from a complex pole or Angle of Arrival (AoA) at a complex zero:

$$\text{AoD from a complex pole : } \phi_p = 180 - \sum_i \angle p_i + \sum_j \angle z_j$$

$$\text{AoA at a complex zero : } \phi_z = 180 + \sum_i \angle p_i - \sum_j \angle z_j$$

- $\sum_i \angle p_i$  is the sum of all angles of vectors to a complex pole in question from other poles,  $\sum_j \angle z_j$  is the sum of all angles of vectors to a complex pole in question from other zeros
- '∠' denotes the angle of a complex number

**Rule 10** Determine whether the RL crosses the imaginary y-axis by setting:

$$1 + KG(s = j\omega)H(s = j\omega) = 0 + 0i$$

and finding the  $\omega$  and  $K$  that solves the above equation. The value of  $\omega$  you get is the frequency at which the RL crosses the imaginary y-axis and the  $K$  you get is the associated gain for the controller. You should obtain two equations (real = 0 and imaginary = 0) with two unknowns ( $K, \omega$ ). From there, you solve for  $K, \omega$  pairs

## Lead Compensator Design Algorithm

- ▶ **Objective:** design  $G_c^{ld}(s) = K \frac{s+z}{s+p}$ , such that  $\zeta_d, \omega_{nd}$  are given
  - ▶ To find  $K, z, p$ , follow this algorithm:
0. Find  $s_d$  for  $s_d^2 + 2\zeta_d\omega_{nd}s_d + \omega_{nd}^2 = 0, s_d = \dots$
  1. Find *angle of deficiency*  $\phi$ , as follows:

$$\theta = \angle G(s_d) \Rightarrow \phi = -180 - (\theta)$$

2. Connect  $s_d$  to the origin
3. Draw a horizontal line to the left from  $s_d$
4. Find the bisector of the above two lines
5. Draw 2 lines that make angles  $\phi/2$  &  $-\phi/2$  with the bisector
6. Their intersections with the real lines are  $-p$  and  $-z$
7. Find  $K$ :

$$1 + KG(s)G_c^{ld}(s) = 0 \Rightarrow \boxed{1 = |KG(s)G_c^{ld}(s)|} \quad \text{here } G_c^{ld}(s) \text{ is without the } K$$

## Ziegler-Nichols Rule: First Method



**Step 1** Obtain plant's unit step response experimentally<sup>1</sup>

- Unit step response is S-shaped for many plants
- Only valid if the step-response is S-shaped

**Step 2** Obtain delay time  $L$  from the experimental plot


**Step 3** Obtain time constant  $T$  from the experimental plot

**Step 4** Use tuning rule table to determine  $K_p$ ,  $T_i$ ,  $T_d$  given  $L$ ,  $T$  (next slide)

---

<sup>1</sup>In industrial applications, control engineers usually specify the performance of the controlled system based on the system step response.

## Obtaining $L$ , $T$ from Experimental Plot



- ▶ Of course, this is an approximation, but you have to be accurate with your computation of  $L$  and  $T$

## Obtaining $K_p$ , $T_i$ , $T_d$ via Tuning Method 1

$$G_c(s) = K_p \left( 1 + \frac{1}{T_i s} + T_d s \right)$$


Type of Controller	$K_p$	$T_i$	$T_d$
P	$\frac{T}{KL}$	$\infty$	0
PI	$\frac{0.9T}{KL}$	$3.3L$	0
PID	$1.2 \frac{T}{KL}$	$2L$	$0.5L$

- ▶ If you want PID control, choose the 3rd row & compute the parameters:

$$G_{PID}(s) = G_c(s) = K_p \left( 1 + \frac{1}{T_i s} + T_d s \right) = 0.6T \frac{\left( s + \frac{1}{L} \right)^2}{s}$$

- ▶ These rules give only the starting point for the design—you might get a better response if you obtain a different set of constants

## Ziegler-Nichols Rule: Second Method



**Step 1** Increase  $K_p$  until step response of the closed-loop system **has sustained oscillations**

- If no oscillation occurs for all values of  $K_p$ , this method is not applicable

**Step 2** Record  $K_{cr}$  (critical value of gain  $K_p$ ) and  $P_{cr}$  (period of the oscillation); see above right figure

**Step 3** Use tuning rule table to determine  $K_p, T_i, T_d$  given  $K_{cr}, P_{cr}$  (next slide)

## Obtaining $K_p$ , $T_i$ , $T_d$ via Tuning Method 2

$$G_c(s) = K_p \left( 1 + \frac{1}{T_i s} + T_d s \right)$$

Type of Controller	$K_p$	$T_i$	$T_d$
P	$0.5K_{cr}$	$\infty$	0
PI	$0.45K_{cr}$	$P_{cr}/1.2$	0
PID	$0.6K_{cr}$	$P_{cr}/2$	$P_{cr}/8$

$$G_{PID}(s) = G_c(s) = K_p \left( 1 + \frac{1}{T_i s} + T_d s \right) = 0.075K_{cr}P_{cr} \frac{\left( s + \frac{4}{P_{cr}} \right)^2}{s}$$

**You should also know how to compute  $K_{cr}$  via the Routh Array analytically rather than experimentally, and then compute  $P_{cr}$ .**

## TF to Controllable Canonical Form

$$H(s) = \frac{Y(s)}{U(s)} = \frac{b_0 s^n + b_1 s^{n-1} + \dots + b_{n-1} s + b_n}{s^n + a_1 s^{n-1} + \dots + a_{n-1} s + a_n}$$

Controllable Canonical form:

$$\dot{\mathbf{x}}(t) = \begin{bmatrix} \dot{x}_1(t) \\ \dot{x}_2(t) \\ \vdots \\ \dot{x}_{n-1}(t) \\ \dot{x}_n(t) \end{bmatrix} = \underbrace{\begin{bmatrix} 0 & 1 & 0 & \dots & 0 \\ 0 & 0 & 1 & \dots & 0 \\ \vdots & \vdots & \vdots & \ddots & \vdots \\ 0 & 0 & 0 & \dots & 1 \\ -a_n & -a_{n-1} & -a_{n-2} & \dots & -a_1 \end{bmatrix}}_{\mathbf{Ax}(t)} \begin{bmatrix} x_1(t) \\ x_2(t) \\ \vdots \\ x_{n-1}(t) \\ x_n(t) \end{bmatrix} + \underbrace{\begin{bmatrix} 0 \\ 0 \\ \vdots \\ 0 \\ 1 \end{bmatrix}}_{\mathbf{Bu}(t)} u(t)$$

$$y(t) = \underbrace{\begin{bmatrix} b_n - a_n b_0 & b_{n-1} - a_{n-1} b_0 & \dots & b_1 - a_1 b_0 \end{bmatrix}}_{\mathbf{Cx}(t)} \begin{bmatrix} x_1(t) \\ x_2(t) \\ \vdots \\ x_{n-1}(t) \\ x_n(t) \end{bmatrix} + \underbrace{b_0 u(t)}_{\mathbf{Du}(t)}$$

**Observable Canonical Form:**

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \\ \cdot \\ \cdot \\ \cdot \\ \dot{x}_n \end{bmatrix} = \begin{bmatrix} 0 & 0 & \cdots & 0 & -a_n \\ 1 & 0 & \cdots & 0 & -a_{n-1} \\ \cdot & \cdot & & \cdot & \cdot \\ \cdot & \cdot & & \cdot & \cdot \\ \cdot & \cdot & & \cdot & \cdot \\ 0 & 0 & \cdots & 1 & -a_1 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \\ \cdot \\ \cdot \\ \cdot \\ x_n \end{bmatrix} + \begin{bmatrix} b_n - a_n b_0 \\ b_{n-1} - a_{n-1} b_0 \\ \cdot \\ \cdot \\ \cdot \\ b_1 - a_1 b_0 \end{bmatrix} u$$

$$y = [0 \quad 0 \quad \cdots \quad 0 \quad 1] \begin{bmatrix} x_1 \\ x_2 \\ \cdot \\ \cdot \\ \cdot \\ x_{n-1} \\ x_n \end{bmatrix} + b_0 u$$

## Diagonal Canonical Form:

$$\frac{Y(s)}{U(s)} = \frac{b_0 s^n + b_1 s^{n-1} + \dots + b_{n-1} s + b_n}{(s + p_1)(s + p_2) \dots (s + p_n)}$$

$$= b_0 + \frac{c_1}{s + p_1} + \frac{c_2}{s + p_2} + \dots + \frac{c_n}{s + p_n}$$

$$\begin{array}{ccc} \Downarrow & & \Downarrow \\ \begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \\ \vdots \\ \dot{x}_n \end{bmatrix} & = & \begin{bmatrix} -p_1 & & & 0 \\ & -p_2 & & \\ & & \ddots & \\ & & & -p_n \\ 0 & & & & \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \\ \vdots \\ x_n \end{bmatrix} + \begin{bmatrix} 1 \\ 1 \\ \vdots \\ 1 \end{bmatrix} u \end{array}$$

$$y = [c_1 \quad c_2 \quad \dots \quad c_n] \begin{bmatrix} x_1 \\ x_2 \\ \vdots \\ x_n \end{bmatrix} + b_0 u$$

## State-space to TF:

$$\dot{\mathbf{x}}(t) = \mathbf{A}\mathbf{x}(t) + \mathbf{B}u(t)$$

$$\mathbf{y}(t) = \mathbf{C}\mathbf{x}(t) + \mathbf{D}u(t)$$

$$\frac{Y(s)}{U(s)} = \mathbf{C}(s\mathbf{I} - \mathbf{A})^{-1}\mathbf{B} + \mathbf{D}$$

## Response of LTI Systems

- ▶ MIMO (or SISO) LTI dynamical system:

$$\begin{aligned}\dot{\mathbf{x}}(t) &= \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t), \mathbf{x}(t_0) = \mathbf{x}_{t_0} = \text{given} \\ \mathbf{y}(t) &= \mathbf{C}\mathbf{x}(t) + \mathbf{D}\mathbf{u}(t)\end{aligned}$$

- ▶ The to the above ODE is given by:

$$\mathbf{x}(t) = e^{\mathbf{A}(t-t_0)} \mathbf{x}_{t_0} + \int_{t_0}^t e^{\mathbf{A}(t-\tau)} \mathbf{B}\mathbf{u}(\tau) d\tau$$

- ▶ Clearly the output solution is:

$$\mathbf{y}(t) = \underbrace{\mathbf{C} \left( e^{\mathbf{A}(t-t_0)} \mathbf{x}_{t_0} \right)}_{\text{zero input response}} + \underbrace{\mathbf{C} \left( \int_{t_0}^t e^{\mathbf{A}(t-\tau)} \mathbf{B}\mathbf{u}(\tau) d\tau \right)}_{\text{zero state response}} + \mathbf{D}\mathbf{u}(t)$$

# Controllability and Observability

## Controllability Test

For a system with  $n$  states and  $m$  control inputs (i.e.,  $\mathbf{B} \in \mathbb{R}^{n \times m}$ ), the test for controllability is that matrix

$$\mathcal{C} = [\mathbf{B} \quad \mathbf{A}\mathbf{B} \quad \mathbf{A}^2\mathbf{B} \quad \dots \quad \mathbf{A}^{n-1}\mathbf{B}] \in \mathbb{R}^{n \times nm}$$

has full row rank (i.e.,  $\text{rank}(\mathcal{C}) = n$ ).

## Observability Test

For a system with  $n$  states and  $p$  outputs (i.e.,  $\mathbf{C} \in \mathbb{R}^{p \times n}$ ), the test for

observability is that matrix  $\mathcal{O} = \begin{bmatrix} \mathbf{C} \\ \mathbf{C}\mathbf{A} \\ \vdots \\ \mathbf{C}\mathbf{A}^{n-1} \end{bmatrix} \in \mathbb{R}^{np \times n}$  has full column rank (i.e.,

$\text{rank}(\mathcal{O}) = n$ ).